



1956 SOLID SIDE GLASS KIT

Includes everything for both doors, tempered glass in choice of clear, tinted or smoke. One piece channels, front run channel brackets, bracket kit, lower felt wipes, hardware and instructions. Oversize shipping (A few Limo Dark Kits left, ASK)

KIT FOR STOCK WINDOW REGULATORS

Includes lower lift channels for stock regulators.

POLISHED STAINLESS BEAD, Clear...	91726-WCC	\$358.50	kit
Smoke ...	91726-WCS	\$358.50	kit
Tint....	91726-WCT	\$358.50	kit
BACK, NO BEAD.....	Clear.....	91727-WCC	\$355.00
	Smoke	91727-WCS	\$355.00
	Tint	91727-WCT	\$355.00

KIT FOR POWER WINDOW KITS

No lift channels, all power window kits come with lift channels.

POLISHED STAINLESS BEAD	\$298.50	kit
Clear...91726-NOC	Smoke...91726-NOS	Tint...91726-NOT
BLACK, NO BEAD	\$299.00	kit
Clear...91727-NOC	Smoke...91727-NOS	Tint...91727-NOT

NO GLASS KIT , Everything but the glass.

Polished stainless bead.....	91728-56NG	\$210.00	kit
Black, no bead.....	91729-56NG	\$210.00	kit

*Order extended lower lift runners if using a stock regulators only.
Laminated glass may break without them, our glass is tempered so does not need them.*

1956 INDIVIDUAL SOLID SIDE PIECES

SOLID SIDE GLASS ONLY	1729-56	\$70.00	ea
<i>Clear, tint, smoke</i>				
LOCK SIDE UPPER & BACK CHANNEL BRACKET				
<i>Holds window channel.</i>				
Driver side, fits 1953-56.....	3114-L	\$40.00	ea
Passenger ,fits 1953-56.....	3114-R	\$40.00	ea
LOWER FELT WIPES, <i>Formed, with clips, does one door</i>				
Stainless bead	1727-56	\$49.00	pr
Black Bead,	1727-56B	\$49.00	pr
Do-yourself, black bead, glue in	1727-BK	\$17.50	pr
Do-yourself, stainless bead, glue in ..	1727-ST	\$17.50	pr
1956 EXTENDED LOWER LIFT RUNNER				
<i>Use these if using stock window regulators, or if not using our tempered glass, laminated glass may break without this support.</i>				
Driver.....	1731-5355XL	\$39.00	ea
Passenger.....	1731-5355XR	\$39.00	ea
GLASS SEAT TAPE KIT	81620	\$5.00	pr
<i>Does both sides, for setting glass into lower lift.</i>				
GLASS FELT CHANNEL				
<i>96" Long. Goes around glass to bottom of door. Shape to fit any door, chop tops, etc Oversize shipping</i>				
Stainless bead.....	3107-UN	\$42.50	ea
Black, no bead.....	3108-B	\$42.50	ea



1956 solid side glass has a right and left, it looks like the same but curve is slightly different, determine correct side before setting in lift channels. Upper and back window channels take a little coaxing into shape. If you are doing solid side windows the channels need to make a complete upside down U shape going all the way up, over and down both sides of glass. If you rush this process the stainless bead will crimp and separate from felt material. Don't try messing with original style clips, glue channels in at original clip points with weatherstrip glue. Lubricate felts with dry graphite, see previous page. See felt bending instructions on page 87