

KICK PANELS • REAR WALL

KICK PANELS

STOCK GRAY PANEL-BOARD KICK PANELS

1953-55	2114-5355.....	\$24.00 pr
1956	2114-56.....	\$24.00 pr

CARPETED KICK PANELS

Can not be used with retainers

Black.....	2115-CBL.....	\$55.00 pr
Color, ask for carpet color samples	2115-(color)	\$65.00 pr
Covered fabric or vinyl.....	2115-(special).....	\$65.00 pr

KICK PANEL TRIM SCREWS

KICK PANEL TRIM BUTTONS

One button or screw for each panel, original was button

ABS KICK PANELS

Order 1953-55 or 1956, needs no retainer, nice rolled edge, paint, cover or leave as is, black textured ABS plastic, attaches with velcro tabs.

1953-55 embossed pattern.....	2117-5355RD	\$89.00 pr
1953-55 smooth.....	2117-5355SM	\$89.00 pr
1956 embossed pattern.....	2117-56RD	\$89.00 pr
1956 smooth.....	2117-56SM	\$89.00 pr
ABS kick panel with ac vent	2114-RND	\$139.00 pr

KICK PANEL RETAINER STRIPS

Made these like originals but to fit better, go completely top to bottom.

RETAINER SCREW SET

.....	82116.....	\$1.50 set
-------	------------	------------

Screws are hidden behind kick panel.

REAR WALL

REAR WALL TRIM SCREW CHROME

.....	82138.....	\$5.50 set
-------	------------	------------

REAR WALL INSULATION

Also see pg. 20

1953-55	92173-5355	\$79.00 kit
1956.....	92173-56	\$79.00 kit

REAR WALL PANEL BOARD SET

.....	2137.....	\$79.00 set
-------	-----------	-------------

1953-55 or 1956 without gas tank. Grey, 2 piece set, oversized shipping

FLAT ABS REAR WALL

.....	2136-F	\$99.95 ea
-------	--------------	------------

53-55 or 56 without tank, easier to use & holds up better than panel board, one flat piece, curves into corners nicely, can paint, cover or leave black, nice pebble texture. Oversized shipping

REAR WALL UPPER EXTENSION

.....	2138.....	\$15.00 ea
-------	-----------	------------

Small flap that holds top of stock panel-board to rear window rubber. Not needed if you are covering the panels with fabric or carpet.

CARPET REAR WALL

Black.....	2152-BK.....	\$48.50 ea
Colors	2152-(color).....	\$55.00 ea

**Panel-board and flat ABS require headliner retainer rubber and clips. See formed style which has built in edge that slips over cab lip, page 23

RUBBER RETAINER

.....	2112.....	\$16.50 ea
-------	-----------	------------

RETAINER CLIPS

.....	2113-SET.....	\$10.00 set
-------	---------------	-------------

ABS FORMED 3 PIECE, NEW STYLE

No rubber retainer needed. Easy install, 3 pieces, sides are contoured to fit and simply clip in. Oversized shipping.

1953-56, smooth.....	2145-SM.....	\$259.00 set
1956, smooth, with big back glass.....	2145-BBSM	\$259.00 set
1953-56, embossed pattern.....	2146-E.....	\$259.00 set
1956, embossed, with big back glass.....	2146-BBE	\$259.00 set

1956 TANK COVER REAR WALL

.....	2139-TNK	\$259.00 set
-------	----------------	--------------

Molded to create a small shelf over tank. Oversized shipping.

Can be trimmed to fit big window.

