

# KICK PANELS • REAR WALL

## KICK PANELS

### STOCK GRAY PANEL-BOARD KICK PANELS

1953-55 .....	2114-5355.....	\$24.00 pr
1956 .....	2114-56.....	\$24.00 pr

### CARPETED KICK PANELS

Can not be used with retainers

Black.....	2115-CBL.....	\$55.00 pr
Color, ask for carpet color samples .....	2115-(color) .....	\$65.00 pr
Covered fabric or vinyl.....	2115-(special) .....	\$65.00 pr

### KICK PANEL TRIM SCREWS

.....	82114-S .....	\$0.95 pr
-------	---------------	-----------

### KICK PANEL TRIM BUTTONS

.....	82114-B .....	\$0.95 pr
-------	---------------	-----------

One button or screw for each panel, original was button

### ABS KICK PANELS

Order 1953-55 or 1956, needs no retainer, nice rolled edge, paint, cover or leave as is, black textured ABS plastic, attaches with velcro tabs.

1953-55 embossed pattern.....	2117-5355RD .....	\$89.00 pr
1953-55 smooth.....	2117-5355SM .....	\$89.00 pr
1956 embossed pattern.....	2117-56RD .....	\$89.00 pr
1956 smooth.....	2117-56SM .....	\$89.00 pr
ABS kick panel with ac vent .....	2114-RND .....	\$139.00 pr

### KICK PANEL RETAINER STRIPS

Made these like originals but to fit better, go completely top to bottom.

### RETAINER SCREW SET

.....	82116.....	\$1.50 set
-------	------------	------------

Screws are hidden behind kick panel.

## REAR WALL

### REAR WALL TRIM SCREW CHROME

.....	82138.....	\$5.50 set
-------	------------	------------

### REAR WALL INSULATION

Also see pg. 20

1953-55 .....	92173-5355 .....	\$79.00 kit
1956.....	92173-56 .....	\$79.00 kit

### REAR WALL PANEL BOARD SET

.....	2137.....	\$79.00 set
-------	-----------	-------------

1953-55 or 1956 without gas tank. Grey, 2 piece set, oversized shipping

### FLAT ABS REAR WALL

.....	2136-F .....	\$99.95 ea
-------	--------------	------------

53-55 or 56 without tank, easier to use & holds up better than panel board, one flat piece, curves into corners nicely, can paint, cover or leave black, nice pebble texture. Oversized shipping

### REAR WALL UPPER EXTENSION

.....	2138.....	\$15.00 ea
-------	-----------	------------

Small flap that holds top of stock panel-board to rear window rubber.

Not needed if you are covering the panels with fabric or carpet.

### CARPET REAR WALL

No backing, just carpet piece, not bound.

Black.....	2152-BK.....	\$48.50 ea
Colors .....	2152-(color) .....	\$55.00 ea

\*\*Panel-board and flat ABS require headliner retainer rubber and clips.

See formed style which has built in edge that slips over cab lip, page 23

### RUBBER RETAINER

.....	2112.....	\$16.50 ea
-------	-----------	------------

### RETAINER CLIPS

.....	2113-SET.....	\$10.00 set
-------	---------------	-------------

### ABS FORMED 3 PIECE, NEW STYLE

No rubber retainer needed. Easy install, 3 pieces, sides are contoured to fit and simply clip in. Oversized shipping.

1953-56, smooth.....	2145-SM .....	\$259.00 set
1956, smooth, with big back glass.....	2145-BBSM .....	\$259.00 set
1953-56, embossed pattern.....	2146-E .....	\$259.00 set
1956, embossed, with big back glass.....	2146-BBE .....	\$259.00 set

### 1956 TANK COVER REAR WALL

.....	2139-TNK .....	\$259.00 set
-------	----------------	--------------

Molded to create a small shelf over tank. Oversized shipping.

Can be trimmed to fit big window.

