

Instructions for: BED WOOD
MID FIFTY F-100 PARTS 1-800-252-1956

PART NUMBER
90214
90215
0213
0215

FIT BEDWOOD BEFORE APPLYING FINISH
As with ANY body part, Bed wood must be pre-assembled for proper fit before adding finish. We suggest assembling for fit and predrilling any holes before applying finish as this protects the wood.
No allowances for bedwood can be made after finish is applied.

Instructions for: BED WOOD
MID FIFTY F-100 PARTS 1-800-252-1956

PART NUMBER
90214
90215
0213
0215

FIT BEDWOOD BEFORE APPLYING FINISH
As with ANY body part, Bed wood must be pre-assembled for proper fit before adding finish. We suggest assembling for fit and predrilling any holes before applying finish as this protects the wood.
No allowances for bedwood can be made after finish is applied.

Instructions for: BED WOOD
MID FIFTY F-100 PARTS 1-800-252-1956

PART NUMBER
90214
90215
0213
0215

FIT BEDWOOD BEFORE APPLYING FINISH
As with ANY body part, Bed wood must be pre-assembled for proper fit before adding finish. We suggest assembling for fit and predrilling any holes before applying finish as this protects the wood.
No allowances for bedwood can be made after finish is applied.

Instructions for: BED WOOD
MID FIFTY F-100 PARTS 1-800-252-1956

PART NUMBER
90214
90215
0213
0215

FIT BEDWOOD BEFORE APPLYING FINISH
As with ANY body part, Bed wood must be pre-assembled for proper fit before adding finish. We suggest assembling for fit and predrilling any holes before applying finish as this protects the wood.
No allowances for bedwood can be made after finish is applied.

Instructions for: BED WOOD
MID FIFTY F-100 PARTS 1-800-252-1956

PART NUMBER
90214
90215
0213
0215

FIT BEDWOOD BEFORE APPLYING FINISH
As with ANY body part, Bed wood must be pre-assembled for proper fit before adding finish. We suggest assembling for fit and predrilling any holes before applying finish as this protects the wood.
No allowances for bedwood can be made after finish is applied.