

- A. Parallel to the frame, front - to - rear
- B. Centered on the frame, side - to - side
- C. Not tilting or leaning

You may find it necessary to loosen (slightly) the front cab mounts to facilitate the completion of this step.

7. With the cab now properly aligned, tighten all cab mounting bolts, including the front ones.

8. Remove the wooden blocks between the frame and cab and lower the truck.

**KEEP YOUR SPIRITS AND TAILGATES UP**

**THANKS FOR BUYING OUR PRODUCT**

