



Applies to Part #, 2146, 2145 and 2148

Cover all pieces with upholstery fabric. Use only a high temp. contact adhesive (3M spray adhesive) start in the center; Spray both the back of the fabric and the panel-- 2 square feet at a time. Working first towards the corners. With the center and corners covered then work your way toward the front. Take your time. If the fabric has a grain pattern keep it straight in the center of the top panel. Place 6 tabs of Dualloc tape (provided) along the center of the roof brace. Remove the red liners and reinstall the headliner center. Once the headliner is in its proper place then press the headliner up until it touches the tabs and locks the headliner into its final place. This will keep it in place and prevent any potential rattling. Reinstall the covered corners and you are finished.

If you have ordered a matching rear cab cover, install it first as the quarter panels act as a finished piece over the lower rear cab cover corners.

Again we are dry fitting

- 1) Slide the rear cab corners into the pinch welds behind each door.
- 2) Fit the center in place between the corners and tuck it under the rubber of the rear window. Once you are confident of the fit, remove all the pieces and cover with fabric, as mentioned above.
- 3) Once covered and ready for installation use the Dualloc tabs along the rear horizon braces, lower and center. Use of the tabs will keep it all in place, and prevent potential rattling.

THANK YOU!