

Instructions for: POLY RIDE SPRING LINER
MID FIFTY F-100 PARTS 1-800-252-1956

INST-2831
2831-F & 2832-R



Poly Ride spring liner should be installed between springs. The U shape legs should point DOWN. We know most companies suggest pointing the legs up but this only collects debris and water, which will cause excess wear and reduce ride. Remember to cut poly liner 1 inch longer on each end when assembling as the spring will flatten when installed on the truck.

Instructions for: POLY RIDE SPRING LINER
MID FIFTY F-100 PARTS 1-800-252-1956

INST-2831
2831-F & 2832-R



Poly Ride spring liner should be installed between springs. The U shape legs should point DOWN. We know most companies suggest pointing the legs up but this only collects debris and water, which will cause excess wear and reduce ride. Remember to cut poly liner 1 inch longer on each end when assembling as the spring will flatten when installed on the truck.

Instructions for: POLY RIDE SPRING LINER
MID FIFTY F-100 PARTS 1-800-252-1956

INST-2831
2831-F & 2832-R



Poly Ride spring liner should be installed between springs. The U shape legs should point DOWN. We know most companies suggest pointing the legs up but this only collects debris and water, which will cause excess wear and reduce ride. Remember to cut poly liner 1 inch longer on each end when assembling as the spring will flatten when installed on the truck.

Instructions for: POLY RIDE SPRING LINER
MID FIFTY F-100 PARTS 1-800-252-1956

INST-2831
2831-F & 2832-R



Poly Ride spring liner should be installed between springs. The U shape legs should point DOWN. We know most companies suggest pointing the legs up but this only collects debris and water, which will cause excess wear and reduce ride. Remember to cut poly liner 1 inch longer on each end when assembling as the spring will flatten when installed on the truck.

Instructions for: POLY RIDE SPRING LINER
MID FIFTY F-100 PARTS 1-800-252-1956

INST-2831
2831-F & 2832-R



Poly Ride spring liner should be installed between springs. The U shape legs should point DOWN. We know most companies suggest pointing the legs up but this only collects debris and water, which will cause excess wear and reduce ride. Remember to cut poly liner 1 inch longer on each end when assembling as the spring will flatten when installed on the truck.