

#CP12030 & #CP12030-D Instructions

for 1955-59 Chevrolet Truck & 1953-56 Ford Truck Front Sway Bar

Note:

This kit will work with stock or drop straight axles.

Make sure this kit fits your application before painting or plating. Parts that have been plated, painted or modified may not be returned.

Instructions:

1. Place front of the truck on jackstands under the axle. The front suspension needs to be loaded when installing the sway bar. Remove the front wheels.
2. The sway bar bolts directly to the front of the axle. Using the u-bolts, fit the sway bar to the axle as shown in the diagrams below.
3. Raise the sway bar up so the ends are parallel with the leaf springs.
4. Assemble the end links and mount them through the hole in the sway bar ends and the hole in the frame bracket. Hold them straight up. Go ahead and clamp the brackets to the frame rail. Measure to make sure the brackets are the same height on both sides. Once the brackets are in the correct position, drill the mounting holes and install the hardware provided to bolt the bracket to the frame rail.
5. Make sure all hardware is tight. Do not over tighten the end link bushing bolts.
6. Reinstall the front wheels and place the truck on the ground. Turn the wheels left and right to make sure there is no binding or rubbing.

