

2907

# #\$%!&@ INSTRUCTIONS

## 2907

# STARTER BUTTON

## MID FIFTY F-100

## PARTS

5221 HIGHWAY 68  
GOLDEN VALLEY AZ 86413  
PHONE 800-252-1956

### 1953-55 STARTER BUTTON INSTRUCTIONS

Starter buttons were original on 1953-1955 and can be used on 6 or 12 volt systems. Both 6 volt and 12 volt applications are shown here.

- 1.....Run a wire (original color was Red w/Blue stripe) from the ACC(12 volt) or GA(6 volt) post on the Ignition Switch to the Starter Button, either side.
- 2.....Run the Red w/Blue Stripe wire out of wiring harness to other side of Starter Button.

If not using our wiring harness the wire should be run to the starter solenoid, center post.

Note that original 1953-55 6-volt Positive ground trucks used both a circuit breaker on the back of the Dash Cluster and a Junction box on the firewall. To wire one of these trucks the circuit goes as follows: Dash Circuit Breaker (inside strapped) to Starter Button, Starter Button to Firewall junction block, Block to Starter Solenoid.

