

Outside sunvisor, steel, with brackets, 1953-55

INST-7990-5355

PART NUMBER:
7990-5355

PAGE NUMBER:
1 OF 1

!@#\$*!@#\$* INSTRUCTIONS

MID FIFTY F-100 PARTS (800) 252-1956 MIDFIFTY.COM



Before you start, you need the following tools: drill gun, hammer, sharp center punch, pliers, screw driver, masking tape, marker & an extra help.



It is recommended that you cover your windshield a sheet of blanket prior to installation to avoid scratches to your windshield.

1. Use masking tape to cover the front portion of the roof above driver side and passenger side to avoid scratching your paint.



2. Install both side brackets and the center bracket to the visor, mount visor to your truck (both sides). Use marker to mark down the holes where the visor will be mounted to (right above the windshield).



3. **Remove the visor off the truck and the center bracket off the visor.** Then use center punch to punch through the metal before drilling the holes with self-taping screws (provided).



4. Once the holes are drilled, mount the center bracket onto the truck. Then mount the visor to your truck, connect the center bracket to your visor, adjust the proper height to your own preference.

You are done!



Last Revision: 11/29/2016