

PART NUMBERS

2125  
82125  
2107

ARM RESTS And  
1953-55 & 1956 DOOR PANELS

#%@# INSTRUCTIONS

MID FIFTY F-100 PARTS 1-800-252-1956

TO LOCATE ARM REST HOLES: Align top line ↑ on this page (template) to top edge of left side panel, & align  
← left line to left side of panel ... then mark & cut holes, note year applications before cutting → ↘



'53-55 HOLE



'56 HOLE

Optional fastener for Upholstered Dr Panel, this may be needed for a flusher fit. Fastener can be cut off if not needed.

Optional Arm Rest holes are marked (not cut) on back of panel or use this template ... cut prior to installation if needed

'56 Door Latch & Window Crank holes are cut larger to accommodate beauty ring

Pre-installed fastener clips align with original door holes. If your door does not have holes, trace the perimeter & fastener locations on a large paper (as gift wrapping paper). Cut out on perimeter & tape to door, then mark hole locations & drill 1/4" holes.

'53-55 HOLE

'56 HOLE

