



Thank you for the purchase of our Advantage Aluminum Truck Bed Floor System. With proper care, you can expect many years of outdoor service.

Care and Maintenance:

Our top coat is a polymer based product with similar chemistry to automotive clear coat. It requires no further maintenance.

Avoid hauling sharp objects in direct contact with our boards. For hauling heavy loads, first place a sheet of ¼" plywood in the bed.

For cleaning simply wash with soapy water or mild detergent, for heavy cleaning isopropyl alcohol can be used.

To install your floor follow the suggestions listed below:

Normally with wooden floors the bed bolts protrude through the wood and cross sills and into the frame to secure the bed to the truck. With our system, install these bolts before the floor is installed there by creating a "Hidden Bolt" system. **DO NOT PENETRATE OUR BOARDS WITH THESE BOLTS AS DAMAGE WILL OCCUR.**

The addition of a fuel inlet in your floor is no problem. Simply install it as any wood floor but fashion a gasket to go between the filler neck and the floor.

Our floor installs similar to any wood floor. You must re-drill ¼" holes into your cross sills at 8 7/16" intervals to accommodate our board width and drill the side boards according to your bed side hole pattern.

Slide the appropriate number of supplied T-Nuts into the center slot of the included floor supports and locate them under the floor between your cross sills to finish the assembly.

If you should have any additional questions, please call Frank at (770) 301-2115.