INSTALLATION INSTRUCT

Fits Those Vehicles That Use A Scrow-On Type Cap As Illustrated.

Step 1. Remove existing fuel cap. Step 2. Notice the existing spring flap unleaded fuel restricter in your vehicle's fuel filler neck. This is the coening which you must



Flap B. Caution: See Step 2 below, How to Fuel-Up. Step 3. Screw on your PermaCap until it is tightly in place.

HOW TO FUEL UP

Step 1. Insert nozzle slowly into your PermaCap. Caution: Insert nozzle slowly into PermaCap to avoid injury from the possible fuel soray which may result from fuel under pressure in your fuel system. Step 2. Before fueling, the fuel nozzle must be inserted all the way down into the opening A while you guide the nozzie to completely penetrate the existing spring flap B unleaded fuel restricter opening. Caution: Be certain to insert fuel nozzle to completely penetrate the existing spring flap B opening of your vehicle's unleaded fuel restricter. Failure to completely penetrate the spring flap B opening may result in fuel splashing back out of the fuel filler neck and may cause serious injury, Step 3. Fill your tank and withdraw nozzle. Recheck your PermaCap periodically to insure that it remains screwed on tightly.



C.A.R.B. No. D 347-1

Lifetime Product Guarantee

PermaCap fuel caps are quality control inspected for materials and workmanship. However, if any PermaCap(s) shall be found defective in workmanship or materials, then such defective PermaCap(s) shall be replaced free of any additional cost or charge to the original purchaser only, provided that any claim under this Guarantee is made in writing to the manufacturer.

Limited Warranty

Notwithstanding anything herein to the contrary, there are no warranties whatsoever which extend beyond the foregoing Lifetime Product Guarantee, All warranties, including any implied warranty of merchantability and fitness for a particular purpose are hereby excluded and the manufacturer shall not be responsible for any incidental or consequential loss or damage resulting from any defective product, including any liability for personal injury, death or property damage. The manufacturer's sole obligation under this Warranty shall be the replacement of any product found to be defective in workmanship or materials. The foregoing Limited Warranty shall be void and of no further force or effect, if the purchaser falls to use or install the PermaCap as set forth in the instruction sheet, if the PermaCap is misused, or if the PermaCap is applied to the vehicle in a manner not prescribed by the manufacturer. This Limited Warranty is not transferable and applies only to the original purchaser of the PermaCap.

Proudly Made in The Good Ole U.S.A.

Kleen Wheels Corporation, Ft. Lauderdale, FL