





Other Outside "Window Down" Switch ***
for backup entry

+ 12 vdc Fused



*** NOTE: Additional Outside "Window Down" Switch and Remote Control are not included in this kit but are shown for wiring clarity. Other connections for the Remote Control are also not shown, Refer to the Remote Control Instructions.



+ 12 vdc (Fuse per motor specs, usually 15 - 20 amps.)

(Ground -run outside door to good chassis ground)

Driver Door

Passenger Door