



Starter Solenoid 12 Volt Negative Ground

(With Two Poll Starter Button)

HORN RELAY

VOLTAGE REGULATOR



•To have Start Button Switched on with Key,
Power is Supplied by the "A" post of the Ignition Switch

•To have Start Button Powered Continuously:
Power is Supplied by the "B" Post of the Ignition Switch