

# Heater switch installation

INST-  
2910  
2911  
1004

#%@&#%@ INSTRUCTIONS  
MID FIFTY F-100 PARTS  
800-252-1956



H ⇨ HIGH ⇨  
ORANGEWIRE  
FROM HEATER MOTOR

B ⇨ POWER ⇨  
FROM ACC POST  
ON IGNITION SWITCH

L ⇨ LOW ⇨  
RED WIRE  
FROM HEATER MOTOR

Ground heater to firewal

