


# DOMELIGHT WIRING W/DIMMER MODULE

**INST-3203-ALL**  
PART NUMBERS  
3203-DM, 3204-L,  
3204-R, 3205, 2256,  
2252-SS, 92250,  
92252, 82252,  
2259-DM

**#@\$!\*#@\$!% INSTRUCTIONS**  
**MID FIFTY F-100 PARTS 1-800-252-1956**

Last Rev: 03/28/2017



If using the dome light dimmer switch with our dome light wiring harnesses please follow these installation instructions.

**A) If mounting the dimmer switch near the dome light frame:**

**ORANGE** wire on the dimmer module connects to the **GREEN** wire powering the dome light (See **AO**).

**RED** wire connects to the **BLACK/BLUE** wire powering the switch at the domelight housing (See **AR**).

**BLACK** wire goes to **GROUND**.

**B) If mounting under the dash:**

**ORANGE** wire connects to green wire powering the domelight, after the driver's side door switch, on the dome light side of the harness, not the headlight switch side. (See **BO**).

**RED** wire connects to power from the D post at the headlight switch (See **BR**).

**BLACK** goes to **GROUND**.