

C 421

1956 Engine Ignition V-8, Manual

- 1. "S" on solenoid**
- 2. "B" on solenoid**
- 3. Temperature sender**
- 4. Oil sender**
- 5. Top of ignition**
- 6. Bottom of ignition**
- 7. "POS" term on coil**
- 8. Ignition switch**
- 9. Ignition switch**
- 10. Ignition harness to chassis harness**
- 11. Oil light**