

# C 423

## 1955 Engine Ignition, V8, manual transmission

1. "S" on solenoid
2. "B" on solenoid
3. Resistor
4. Resistor
5. Sender Oil
6. "POS" coil
7. Ignition switch
8. Ignition switch
9. Oil light

