C 4599

1956 Engine Ignition V8, Manual W/A.C.

1. "S" on Solenoid
2. "B" on Solenoid
3. Temperature Sender
4. Oil Sender
5. Top of Ignition Resistor
6. Bottom of Ignition Resistor
7. "POS" term on coil
8. Ignition Switch
9. Ignition Switch
10. Ignition Harness to Chassis Harness
11. Oil Light