C 8410

1957 Ignition V8 Auto W/Fuel Injection

1. "S" on Solenoid
2. "C" on Solenoid
3. "B" on Solenoid
4. Temperature Sender
5. Top of Ignition Resistor
6. Bottom of Ignition Resistor
7. Oil Sender
8. "POS" terminal on the coil
9. Neutral safety switch
10. Ignition Switch
11. Ignition harness to chassis harness
12. Oil Light